



Yaber




Quick Start Guide

U11 PROJECTOR **EN**


Package Contents




U11 Projector




HDMI Cable




3-in-1 AV Cable




Remote Control



Power Cord



Cleaning Cloth









Lens Cover




Quick Start Guide


Product Overview



Turn on Yaber Projector



Connect Devices



Yaber U11 projector has 7 interfaces, HDMI ports*2/USB ports*2/AV in/3.5mm headphone output/RJ45(Network port). Please select the correct connecting ports to connect your device(PC, Phone, DVD Player, Sound bar, USB, PS4 etc.)


Connect the Devices via the HDMI ports

1. Connect your TV stick or laptop to any HDMI port of the projector.
2. Enter the home page to select the HDMI as the signal source.

Wireless Connection



1. iOS Cast (for iOS Devices)

1. Go to home page - Press the left button - Select the [Network] menu - Select [Wireless Net Mode] - Select your home WiFi from the list - Connect the U11 projector to your home WiFi



2. Select the [Settings] menu on your iOS device - Turn on the [Wi-Fi] function - Connect your iOS device and projector to the same network.


3. Open the [Control Center] on your iOS device - Select the [Screen Mirroring] function - Select and connect the iOS Cast receiver named [XXXXX] - Your iOS device screen will be displayed on the projection screen after 3 seconds.



2. Miracast (for Android Devices)

1. Make sure U11 projector and your Android device are connected with the same Wi-Fi, operations refer to the [1] and [2] from iOS Cast (for iOS Device).

2. Go to home - Select the [Maxhub Share] app - Press the OK button to enter the [Maxhub Share] app.



Miracast

To connect Android Mobile with Projector Based on
WIFI-Display Technology





3. Scan the QR code and download the app on your Android device.

4. Open [Maxhub Share] app on your Android device - Select TV named [XXXXX] - Your Android device screen will be displayed on the projection screen after 3 seconds.

Adjust the Angle and Definition

When using the projector for the first time, usually the displayed image is not clear. This is caused by a lens being out of focus or an incorrect keystone setting. Please follow the steps below to correct it.

Focus Adjustment



When starting the U11 projector for the first time, please wait patiently for 2-3 seconds, the projector will automatically adjust the focus. If the image is not clear, you can press the focus button "F+", "F-" to adjust the focal length of the lens, click or long press the focus button until the image is clear.

Note: If it is still blurry, please try to adjust the projection distance.

Bluetooth Setting

1. Open your Bluetooth device.

2. Go to home page - Select the [Setting] menu - Select the [Bluetooth] option - Open the Bluetooth function and your Bluetooth device - Select your Bluetooth device nearby automatically - Choose the Bluetooth device desired - It will be paired and connected automatically.

Note:

The U11 projector is compatible with the Bluetooth headsets, Bluetooth speakers and Air Pods, but not the Bluetooth keyboards or Bluetooth phones.



Scan and download the PDF user manual

Where to Get More Help

✉ aftersales@yaber.com

🌐 www.yaber.com

▶ @Yaber Entertainment Projector

📺 @Yaber Entertainment Projector